



400 High Grove Blvd  
Glendale Heights, IL 60139  
Telephone: 1-800-486-6800  
Fax: 1-800-430-6807

## Natural Textiles

### Installation Instructions

Natural Textiles is a collection of natural textile wallcoverings, thus subtle variations in color and weave should be expected within each bolt. Although extreme care is taken during the weaving process, these inherent characteristics are a part of these natural wallcoverings intrinsic beauty, and should be considered neither flaws nor imperfections.

#### **Check Before Cutting:**

The first step you should take is to confirm that all the materials you have received match what was ordered and are correct regarding the pattern number, color, and width. Before proceeding with the installation, make a final inspection to verify the run numbers of each bolt and check for any noted flaws in the material. Take a moment to make sure that you have sufficient material on hand to complete this job. This is a natural product and as such will exhibit subtle color or weave variations between the samples and the actual delivered materials as well as between different runs/dye lots. These variations are to be expected as they are inherent characteristics of natural wallcoverings and cannot be avoided.

**NO CREDIT WILL BE ALLOWED FOR CUTTING OR INSTALLING INCORRECT PATTERNS OR COLORWAYS.** Application of materials is interpreted as acceptance of the material and conditions of the installation.

Should you have any questions please contact your local Kravet sales representative, Kravet showroom, or Winfield Thybony Design customer service at 800-486-6800 before proceeding.

#### **Surface Preparation:**

Ensure surfaces are dust free, smooth, dry, firm and uniformly colored or primed. Do not install over non-porous surfaces. Previously painted walls may be wiped down with Tri Sodium Phosphate to remove any grease or oil. Glossy paint should be dulled by sanding. Never install these materials over new plaster or un-primed walls. It is best to prime all surfaces with an appropriate high quality acrylic wallcovering primer.

All surfaces to receive wallcoverings should be tested and approved by the installer to determine suitable adherence of existing coatings.

#### **Preparing the Material:**

All rolls are numbered and should also have a common production number. Never use wall coverings from different production runs on the same wall. Use rolls in sequence starting with the highest number. Hang in sequence as cut from the roll and avoid in-filling above the doors, windows, etc. Do not reverse strips.

Wallcoverings made from natural materials will sometimes have faults. Where faults do occur however, they are clearly marked with tags. The use of natural fibers may also result in slight color variations.

#### **Adhesive:**

You **MUST** use a quality grade of heavy-duty premixed clear strippable adhesive. Do not dilute. Using another type of adhesive will be solely at the risk of the installer.

#### **Installation:**

Wallcovering shall be installed by professional experienced workers and contractors in strict accordance with these instructions.

Using the **highest bolt number first**, start by cutting strips to the height of the wall plus 2" to allow for trimming at the ceiling and floor. Use only a graphite pencil and mark the backing by numbering the strips in cutting order for proper sequencing. Mark the top and bottom to maintain straight or reverse hanging progression. **Handle the cut strips with care to avoid damage to the pre-trimmed edges.**

Apply adhesive to the substrate using a short-napped synthetic roller. Take care not to get adhesive on the surface of the material. Paste 8" beyond the width of each strip so that you do not get adhesive on the first strip when you have to paste the next one. Should you get adhesive on the surface of the material it may be impossible to remove. If this occurs, remove the adhesive immediately with a damp sponge and dry the surface with a clean dry towel.

Place the first strip on the wall with its trimmed edge against the plumb line and allow the material to overrun a little at the ceiling and the floor. Use a flexible spatula with rounded corners to smooth the material against the wall, eliminating any air pockets. Start from the middle and work upwards and downwards.

**Installation:** The wallcovering is pre-trimmed and therefore it can be butt jointed. Should the material have a repeat, it will need to be carefully trimmed on a cutting table at the appropriate repeat dimension.

Avoid the use of a hard roller or overworking the seams, as this may damage the edges. Use a soft rubber roller only is necessary, and then with gentle pressure only.

After 3 strips have been hung, use a sharp blade and a spatula to trim the excess material at the ceiling, floor and corners. Always keep the knife blade in the cut while moving a flexible spatula with rounded corners forward. Use a fresh blade for each cut.

Use only full width material. Avoid cutting in narrow widths of material above doors and window frames. In particular, do not in-fill with off cuts or out of sequence strips. If you do have to hang a partial width make sure the joint on the wall is made with two pre-trimmed edges, reversing "if required". **Never join the middle of a strip to a pre-trimmed edge.**

Check each drop for shading as you proceed. Never assume shading is caused by moisture and that it will disappear on drying.

**Test Hanging:** **STOP AFTER APPLYING 3 STRIPS.** If there are any excessive variations in color and/or color match, this should be immediately communicated to your local Kravet sales representative, Kravet showroom, or Winfield Thybony Design customer service at 800-486-6800 before proceeding further with installation. Natural Textile wallcoverings will tend to slightly panel on occasion.

**Winfield Thybony Design assumes no responsibility for the installation of material beyond 3 strips. Under no circumstances will Winfield Thybony Design be responsible for labor. This is an industry standard.**

The above information is intended only as a guideline; the installer has final responsibility for proper installation.

**Natural Textiles is Marketed Nationally by Kravet Inc.**