



## Performance Wallcoverings Installation

**Inspection:** The installer should review all material before installation. Verify that you have the correct pattern, run number, color and quantity to complete. Identify any apparent defects in craftsmanship at this time and call Winfield Thybony customer service to notify of any concerns before proceeding.

No claims, including labor, will be accepted beyond the installation of 3 strips. Installation of the wallcovering is interpreted as acceptance of material and conditions of installation. Slight differences in shading or subtle differences between sample and actual delivered material cannot be avoided. Should you have any questions please contact your local Kravet sales representative, Kravet showroom, or Winfield Thybony Design customer service at 800-486-6800 before proceeding.

**NO RETURNS will be accepted after the material is cut.**

**Surface Preparation:** All surfaces must be clean, dry, smooth, free of all prior adhesive residue and structurally sound. Sand finish plaster must be scraped smooth. A level 4 Gypsum Assoc finish level is the minimum. Cement block must be plastered or floated smooth before application of wallcovering. Newly plastered walls must be thoroughly dry before application. Walls that are tightly sealed with several coats of paint must be opened with rough sandpaper to aid in bonding.

The use of a high quality pigmented wallcovering approved primer is recommended.

- Application:**
1. Cut material in consecutive bolt sequence, if rolls are so marked on the end of each wrapper.
  2. A pre-mixed, heavy-duty vinyl adhesive (i.e. Roman Pro 774 or 880) should be used. Do not dilute.
  3. Apply the recommended adhesive to the back of the material using either a pasting machine or paint roller. Fold each end towards the middle, pasted sides together, aligning the edges carefully so they do not dry out. Do not crease the material. Allow the material to book for 10 minutes. This will allow the adhesive to penetrate the fabric backing, which is important for a successful installation.
  4. Use strips in exact order as they are cut from the roll. Reversing strips may reduce shading at the seams if a random pattern. Fill in over doors and windows as they come with strips cut in consecutive order from the roll. Hang only 1-2 strips at a time. Seams should be overlapped and double cut.
  5. Smooth material to hanging surface with a plastic smoothie or soft bristle to eliminate air bubbles and ensure adhesion. Remove paste immediately from surface with clean warm water using a clean and damp sponge. Change the water often. Take care to not flood seams when cleaning.

STOP AFTER APPLYING 3 STRIPS. If there are any variations in color and/or color match, this should be immediately communicated to your local Kravet sales representative, Kravet showroom, or Winfield Thybony Design customer service at 800-486-6800 before proceeding.

**Winfield Thybony assumes no responsibility for the installation of material beyond 3 strips. Under no circumstances will Winfield Thybony be responsible for labor. This is an industry standard.**

Marketed Nationally by Kravet Inc.

Winfield Thybony Wallcovering  
400 High Grove Blvd. Glendale Heights, IL. 60139  
800.486.6800 / Fax 800.430.6807 / winthy.com