



400 High Grove Blvd
Glendale Heights, IL 60139
Telephone: 1-800-486-6800
Fax: 1-800-430-6807

Pinnacle

Textured Non-Woven Wallcoverings

Installation & Maintenance Instructions

Inspection:

Be sure all material has the same run number before installation. Final inspection should be made as to correct pattern, color, and any apparent manufacturing defects. No claims, including labor, will be accepted beyond the installation of 3 strips. Application of material is interpreted as acceptance of material and conditions of installation. Slight differences in shading between different run lots or subtle differences between sample and actual delivered material cannot be avoided.

Should you have any questions, contact your Winfield Thybony Sales Representative or Customer Service 800-486-6800 before proceeding.

Surface Preparation:

Ensure surfaces are dry, firm, and uniformly colored. Do not hang over glossy or non-porous areas. Painted walls should be wiped down with Tri Sodium Phosphate to remove grease or soil. Glossy paint should be dulled by sandpaper. Never hang over new plaster or un-primed wall areas. For wallboard or drywall, fill all cracks and prepare the surface using a high quality pigmented acrylic wallcovering primer.

Application:

1. Apply a pre-mixed, heavy-duty clear vinyl adhesive to the back of the material. Make sure the adhesive is spread out evenly over the whole surface to insure good adhesion to the wall. This will avoid open seam. Do not dilute the adhesive. Never allow the adhesive to get on the front of the material.
2. Use strips in exact order as they are cut from the bolt. The material may be applied immediately without booking. Do not fold the sheets, as the material can crease as a result. Pinnacle patterns should be hung in accordance with the instructions in each roll. The strips should NOT be reversed; with the exception of Cassels which needs to be reversed for proper pattern match.
3. Cut material in sequential bolt sequence, as marked on the end of each wrapper. The manufacture ships the material pre-trimmed. Strips should be butted along the seams and evened with a seam roller if necessary.
4. Carefully smooth material to hanging surface with a soft bristle to eliminate air bubbles and ensure adhesion. Avoid getting paste on the surface of the wallcovering. Any paste residue that gets on the surface of the wallcovering must be removed immediately with a sponge and clean water – gently dabbing the area.
5. STOP AFTER APPLYING 3 STRIPS. If there are any variations in color and/or pattern match, this should be immediately communicated to Winfield Thybony Design for inspection before proceeding further with installation. Pinnacle wallcoverings may tend to slightly panel on occasion.

Winfield Thybony Design assumes no responsibility for the installation of material beyond three strips. Under no circumstances will Winfield Thybony Design be responsible for labor. This is an industry standard.

Cleaning:

Remove stains immediately with a clean sponge and water. Blot dry with a clean towel. Avoid hard rubbing and the use of too much water. Excessive water or soaking will damage the wallcovering.

Special Note:

Pinnacle wallcoverings have been manufactured to the highest quality standards possible. However, it should be noted that some items by their nature, require care and special handling when installing the material so as to provide an acceptable wall finish.

The information shown above is intended only as a guideline; the installer has final responsibility for proper installation.