

400 High Grove Blvd Glendale Heights, IL 60139 Telephone: 800-486-6800 Fax: 800-430-6807

Shimmer

Installation Instructions

Inspection: Be sure all material has the same run number before installation. Final inspection should be made as to correct pattern, color, and any defects in craftsmanship.

No claims, including labor, will be accepted beyond the installation of 3 strips. Application of material is interpreted as acceptance of material and conditions of installation. Slight differences in shading between different run lots or subtle differences between sample and actual delivered material cannot be avoided. Should you have any questions, contact your Winfield Thybony representative or customer service 800-486-6800 before proceeding.

NO RETURNS will be accepted after the material is cut.

- Surface Ensure surfaces are dry, firm, and uniformly colored. Do not hang over glossy or non-porous areas. Painted walls should be wiped down with Tri Sodium Phosphate to remove grease or soil. Glossy paint should be dulled by sandpaper. Never hang over new plaster or unprimed wall areas. For wallboard or drywall, fill all cracks and prepare the surface with an acrylic basecoat. Prime all surfaces using a high quality pigmented acrylic wallcovering primer.
- Application: 1. Apply a pre-mixed, heavy-duty clear vinyl adhesive to the back of the material. Make sure the adhesive is spread out to the edge of the material to insure good adhesion to the wall. This will avoid open seams. Do not dilute the adhesive. Never allow the adhesive to get on the front of the material. Book the wallcovering and allow to relax for five minutes before applying to the wall.
 - 2. Material should be installed by reversing strips. Wallcovering should be installed in the exact order as cut from the rolls.
 - 3. Smooth material to hanging surface with a soft bristle smoothing brush to eliminate air bubbles and ensure adhesion.
 - 4. STOP AFTER APPLYING 3 STRIPS. If there are any excessive variations in color and/or color match, this should be immediately communicated to your Thybony representative or Customer Service before proceeding further with installation.

Winfield Thybony assumes no responsibility for the installation of material beyond three strips. Under no circumstances will Winfield Thybony be responsible for labor. This is an industry standard.

Cleaning: Clean using warm water and a mild soap or degergent. Do not use any abrasive cleaners.