



400 High Grove Blvd
Glendale Heights, IL 60139
Telephone: 800-486-6800
Fax: 800-430-6807

Barclay Butera

Printed Grasscloth Installation Instructions

- Inspection:** These wallcoverings are hand screened designs.
- Be sure all material has the same run number before installation. Final inspection should be made as to correct pattern, color, and any defects in craftsmanship. As this is a natural handmade product, these materials have a tendency to show color variation. These variations are natural and inherent qualities of the wallcovering.
- Surface Preparation:** Previous wallcovering must be removed. Walls must be structurally sound, dry, sealed and clean. Wall surfaces shall be free from defects and imperfections that could show through the finished covered surface. Prime with a high quality acrylic wallcovering primer.
- Cutting:** Handprinted grasscloth wallcoverings are shipped untrimmed. Take care to accurately table trim the edge of each sheet. Be sure edges are even before installation. Each shipment contains bolts marked with consecutive numbers. This is the order in which the product was manufactured and should be followed in installation.
- Adhesive:** You MUST use a high wet tack heavy-duty clear strippable adhesive. Do not dilute. Using another type of adhesive will be solely at the risk of the installer. Grasscloth wallcoverings are not strippable or peelable. Apply an even coat of adhesive to the back of the wallcovering. Allow the adhesive to become tacky before applying to wall. Be cautious not to allow adhesive to touch the face of the goods.
- Test Hanging:** Test hang three strips and carefully review materials and application. STOP AFTER APPLYING 3 STRIPS. Small differences in shading between different run lots or subtle differences between sample and actual delivered material cannot be avoided. Should you have any questions, contact your local Kravet sales representative, Kravet showroom, or Winfield Thybony Design customer care at (800)486-6800 for inspection before proceeding further with installation.
- Installation:** **Wallcovering shall be installed by experienced workers and contractors in strict accordance with these instructions.**
- Material must be dry table trimmed. **Do not double cut.** Apply material to wall using a soft brush to eliminate air bubbles and ensure adhesion. Align the print according to the directions and product information found for your specific pattern at winfieldthybony.com, where the type of match and size of the repeats will be identified.
- Care & Maintenance:** Dust can be removed with a vacuum cleaner or special textile sponge (used like an eraser).
- Special Note:** Barclay Printed Grasscloth wallcoverings have been manufactured to the highest quality standards possible. However, it should be noted that some items by their nature, require care in handling and installing so as to provide an acceptable wall finish.



400 High Grove Blvd
Glendale Heights, IL 60139
Telephone: 800-486-6800
Fax: 800-430-6807

Barclay Butera

Grasscloth & Paperweave Installation Instructions

- Inspection:** Be sure all material has the same run number before installation. Final inspection should be made as to correct pattern, color, and any defects in craftsmanship. As this is a natural handmade product, these materials have a tendency to show color variation. These variations are natural and inherent qualities of the wallcovering.
- Surface Preparation:** Previous wallcovering must be removed. Walls must be structurally sound, dry, sealed and clean. Wall surfaces shall be free from defects and imperfections that could show through the finished covered surface. Prime with a high quality acrylic wallcovering primer.
- Cutting:** The un-printed grasscloth and paperweave wallcoverings are shipped pre-trimmed. Be sure edges are even before installation.
- Adhesive:** You **MUST** use a high wet tack heavy-duty clear strippable adhesive. Do not dilute. Using another type of adhesive will be solely at the risk of the installer. Grasscloth wallcoverings are not strippable or peelable. Apply an even coat of adhesive to the back of the wallcovering. Allow the adhesive to become tacky before applying to wall. Be cautious not to allow adhesive to touch the face of the goods.
- Test Hanging:** Test hang three strips and carefully review materials and application. **STOP AFTER APPLYING 3 STRIPS.** Small differences in shading between different run lots or subtle differences between sample and actual delivered material cannot be avoided. Should you have any questions, contact your local Kravet sales representative, Kravet showroom, or Winfield Thybony Design customer care at (800)486-6800 for inspection before proceeding further with installation.
- Installation:** **Wallcovering shall be installed by experienced workers and contractors in strict accordance with these instructions.**
- Material is shipped pre-trimmed. Apply material to wall using a soft brush to eliminate air bubbles and ensure adhesion.
- Care & Maintenance:** Dust can be removed with a vacuum cleaner or special textile sponge (used like an eraser).
- Special Note:** These grasscloth and paperweave wallcoverings have been manufactured to the highest quality standards possible. However, it should be noted that some items by their nature, require care in handling and installing so as to provide an acceptable wall finish.